

INSTRUCTIONS

360 Y-DROP® BREAKAWAY

The breakaway will be mounted in the same location that the riser mount would normally be.

⊕ INSTALLATION

Figure 1

Step 1 While supporting breakaway (1) on the rear of the 360 Y-DROP boom, install square U-bolts (2), with the threads facing to the back, and the extra thick washers and nuts (3).

Figure 2

Step 2 Install riser mount (1) using the square U-bolts (2) and the extra thick washer and Nylock nut.
Hardware Kit C

Figure 3

Step 3 Install riser tube assembly (1) into the riser mount and install pin (2).

Repeat Steps 1-3 for the remaining riser tube assemblies.



Figure 1



Figure 2

Figure 3

⊕ INSTALLATION COMPLETE.