



Cleanup and Storage Guidelines: 360 Y-DROP and 360 UNDERCOVER

The below tips for cleaning and storage are in addition to regular sprayer clean out instructions.

- Clean out lines by pumping water through your sprayer and the 360 Y-DROP™ system to remove residual chemicals.
- Rinse and clean out nozzles. Make sure to inspect for any plugged or worn out nozzles and check for missing or damaged rubber washers.
- Inspect hoses (both extension and drag) for any leaks via pinholes, wear, loose clamps, etc.
- Clean 360 Y-DROP bases and 360 UNDERCOVER™ units thoroughly to remove any mud, debris and chemicals. Inspect for cracks and loose or missing fasteners.
- Check 360 Y-DROP boom structure for any damaged pieces and note for replacement.
- If there is bare metal showing on the risers or any other metal component due to normal wear, clean surface of any contaminants and loose paint. Repaint prepared areas with appropriate paint to prevent rust and corrosion.
- If removing 360 Y-DROP system from sprayer, make sure to record mounting locations for quick installation for the next use.
- You can choose to completely disassemble your 360 Y-DROP system to save space or to partially disassemble to save time on installing the system for future use.

As always, if you have questions or need help, reach out to your Regional Agronomy Manager, or call the Support Center at 888-512-4890.